

Sherpa Fleece Heated Throw

Size – 150 X 190 CM



Thank you

Hello, thanks for choosing to purchase your heated throw from Dreams - you're now on your way to getting warm and cosy. Before you start using your throw, please take a moment to read through the instructions.



Top tip

Wrap yourself underneath this blanket when on the sofa or in your armchair to keep yourself warm throughout the day or evening.



Safety and care

All plastic and wrapping materials should be kept away from children and animals to prevent any risk of suffocation. Please familiarise yourself with the important safety instructions contained within this manual.



Help and support

At Dreams, it's our mission to give the whole nation a great night's sleep - this means that the quality of our products is of utmost importance to us. If there are any issues with your product or any missing parts, please visit our website at www.dreams.co.uk/help



Recycling

Please ensure that packaging is disposed of in a safe and environmentally friendly way and recycle where possible. Our assembly instructions are printed on recycled paper. Please keep your assembly instructions safe to refer back to in the future.

Important safety instructions

When using electrical appliances, in order to reduce the risk of fire, electrical shock, and / or injury to persons, basic safety precautions should always be followed including the following:

- Carefully read the manual and keep it for future reference. Familiarise yourself with the operation of the Heated Blanket and how to use it.
- Connect the Heated Blanket only to sockets with the voltage indicated on the rating plate (AC only).
- The product can be used by children over 8 years of age. Also, individuals with reduced physical, sensory, or mental abilities, or a lack of experience and/or knowledge, provided they've been supervised or instructed on the safe use of the product and understand the potential dangers.
- Please be particularly careful when using the product near children. Don't allow them to play with the product. Additionally, don't allow individuals who aren't familiar with the product to use it without prior instruction.
- This product must not be used by individuals who are sensitive to heat (e.g. danger of unnoticed burns). Nor by those who wouldn't be able to react to overheating (e.g. physically restricted individuals who wouldn't be able to free themselves).
- Children under the age of 3 years must not use this product, as they are unable to react properly to overheating.
- Inspect the Heated Blanket regularly for signs of wear, tear, or damage. Do not use it if you spot any of these. Instead, contact a qualified technician for repairs.
- If the power cord of this product is damaged, it should only be replaced by a qualified technician to avoid danger.
- Do not use the Heated Blanket in combination with other heating devices.
- Turn off the control panel before inserting or removing the plug. Always remove the cable by pulling the plug and not the cable.
- The blanket must always be used only in the fully spread condition.
- Do not switch the power on if the blanket is wet or folded.
- Do not leave the product unattended during operation. Turn the switch off and remove the power plug when the Heated Blanket is not in use or before cleaning it.
- When storing, fold or roll neatly and without sharp bends in the heating wire. Do not store other items on top of this blanket. Only store when the blanket has fully cooled.

- Do not use the Heated Blanket when it's damp or wet.
- Do not touch the product or the adapter with wet hands.
- Do not use devices such as hair dryers or clothes dryers for drying. Allow the blanket to dry by air.
- Do not immerse the cord, plug or the entire product in water or other liquids.
- Do not expose the product to environmental conditions (rain, sun etc.) and do not use the product in high humidity areas or the bathroom.
- Do not insert any sharp objects into the Heating Blanket.
- Take care not to pinch the blanket and cable when using it.
- Do not use the product in a folded or crumpled state and do not tuck it in.
- Use this Heated Blanket as an over-blanket only. It should not be used with futons or similar folding bedding systems.
- When used on your bed, ensure there are no heavy objects on the blanket and that it is not positioned below your pillows.
- Never cover the controller.
- Do not iron the Heated Blanket.
- This Heated Blanket is not a medical product and is not suitable for therapeutic purposes.
- Overuse of the blanket at a high heat setting may result in skin irritation.
- Connect the control element to the Heated Blanket before you plug the power plug into the power outlet.
- Only use this blanket with the control unit provided (RU1-1A/T9).
- The product is equipped with an overheating protection. If this fuse is triggered, the product will no longer function. In this case, contact a qualified technician.
- Ensure that the Heated Blanket does not overhang the mattress.
- Do not dry clean this Heated Blanket as cleaning solutions may corrode the insulation. Clean this blanket only following the instructions provided.
- This blanket is for human use only, do not use with pets.
- This Heated Blanket must not be used over or under a waterbed.

Intended use

The Blanket is not a medical device and is not suitable for therapeutic purposes or within hospitals. The Heated Blanket must not be used to warm babies, infants, helpless or heat-insensitive individuals or animals. Use only in dry indoor rooms. Use the product only for its prescribed purpose.



Important: Read these instructions carefully and thoroughly. Keep these instructions to read through at a later date. If you give the product to anyone else at some point in the future, please ensure you also pass on this manual.



Do not bleach



Do not iron



Do not insert pointed objects



Wash at maximum of 40°C in the gentle wash cycle (for models with removable control element).



Do not tumble dry



Do not dry clean



Do not use in a folded or crumpled condition



Not to be used by very young children (0-3 years)




Only for domestic use and not for commercial use!

Operating instructions

Place the Heated Blanket over your body ensuring there are no folds or crumples. The side with the socket (shown in the image directly below) should be facing upwards and not against your body.

Ensure that the plug of the controller is inserted firmly into the socket on the blanket and then insert the plug into the mains power outlet.




LED Display

Temperature Setting Button

Countdown Timer Setting Button

ON / OFF Switch



Operating the Controller

Firstly, slide the ON / OFF switch upwards so the notch on the switch is aligned with the number "1".

You will notice two red numbers in the LED display. The number on the left refers to the heat setting and the number on the right refers to the countdown timer setting.

Press the "Temp" button repeatedly to select your desired heat setting. Setting "0" has no heat setting. Setting "1" gives the lowest heat with "9" being the maximum.

Press the "Timer" button repeatedly to select the desired operating hours. The numbers 1-9 are shown in hours and "H" represents 12 hours. The blanket will operate until the selected time period has elapsed. When the time has run out the blanket will stop heating and the LED display will switch off. To restart the blanket, slide the ON / OFF switch downwards to "0" and then upwards to "1".

If using for a prolonged period of time it is recommended to set the temperature setting to "9" for the first hour and then decrease the setting to between "1" and "4" for the remaining time.

Important: When the blanket is not in operation, please slide the ON / OFF switch downwards to "0" and disconnect from the mains power supply.

Care and maintenance

Here are some tips to keep your Heated Blanket in tip-top condition. Please don't dry clean, tumble dry, or iron your Heated Blanket to avoid damage.



Spot cleaning

Sponge the dirty area using a warm soapy solution and when clean sponge the same area lightly with warm water. Remove any excess water using an paper towel or absorbent cloth and then leave to fully dry before use.



Machine washing

Always disconnect the control panel from the electric blanket before washing. Wash at maximum 40°C for a gentle wash.



Hand washing

Always disconnect the control panel from the electric blanket before washing. Do not wring your Heated Blanket.



Drying

Let your Heated Blanket dry naturally by air, do not tumble dry or use a hair dryer or clothes dryer to dry it. If you are hanging it to dry please drape it over the line and don't use pegs.



Storage

When not in use, fold your Heated Blanket and store in a cool, clean and dry location. Avoid pressing sharp creases into your blanket when folding. Only fold and store your blanket when it's fully cooled down.

Thank you for shopping with us.

Sleep well

Technical information

Model number: 769-00445

Controller: RU1-1A/T9

Blanket size: 150cm x 190cm

220-240V ~ 50Hz

150W



The 'whee bin' symbol is known as the 'Crossed-out whee bin Symbol'. When this symbol is marked on a product/ batteries, it means that the product/ batteries should not be disposed of with your general household waste. Only discard electrical/electronic/battery items in separate collection schemes, which cater for the recovery and recycling of materials contained within. Your co-operation is vital to ensure the success of these schemes and for the protection of the environment. For your nearest disposal facility, visit www.recycle-more.co.uk

Dreams