


Nocturna TV Bed

Sleepmotion Lifestyle



1.5 hour approx
assembly time



Two person
assembly

Dreams
Love your bed

MK1 250317

Thank You

Dear Customer, Thank you for choosing to purchase your bed from Dreams - we hope it brings you your best ever night's sleep. Before you begin building your bed, please take a moment to read through the instructions and make sure that you've got all the relevant parts listed on the following pages.



Assembly tips

Before you begin, it's best to identify all parts and fittings to build your bed. We advise laying these out on the floor to check you have everything, and familiarising yourself before building.



Top tip

We recommend that you build your new bed in the room you'd like it to be located - this will help prevent any risk of damage to your newly built bed whilst moving it.



Safety and care

It's really important to ensure children and animals are kept away from the assembly area, as there are small components used in this bed which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation. To keep your little ones busy, there is a colouring page inside the back cover.



Help and support

At Dreams, it's our mission to give the whole nation a great night's sleep - this means that the quality of our products is of utmost importance to us. If there are any issues with your product or any missing parts, please visit our website at www.dreams.co.uk/help



Recycling

As part of our zero to landfill policy, we're more than happy to collect and recycle your old bed or mattress, ensuring no part goes to waste. We will also take away all your packaging for recycling at point of delivery. Please check out our services on www.dreams.co.uk/recycling-services for more information. If you do not want us to do this, please check with your local recycling centre on the best recycling method.


Parts

Important information

The bed you have purchased comes with an electric Sleepmotion base. Please follow the instructions that came with the base in the order described.

Once the base is built please follow the instructions to build your frame around the Sleepmotion base itself.


A



Description: Headboard

Qty:1
CTN: 1


B



Description: Footboard

Qty:1
CTN: 2


C



Description: Side Rails

Qty: 2
CTN: 3L


M



Description: Mains Power
Lead 3.5 metre

Qty:1
CTN: 2


N1



Description: HDMI 2.1 Cable
5 metre-8K

Qty:1
CTN: 3L


N



Description: HDMI 2.1 Cable
2.8 metre-8K

Qty:2
CTN: 2


O



Description: Remote Control
Holster

Qty:1
CTN: 2


P



Description: HDMI 90°
adaptor

Qty:1
CTN: 2


Q



Description: Cable Clips

Qty:5
CTN: 2


R



Description: Cable Ties

Qty:5
CTN: 2


S



Description: Long Connection
Cable - DB15 pin

Qty:1
CTN: 2


T



Description: 2.1 Audio_TV
Lift Remote
Control


Qty:1
CTN: 2

Z



Description: TV Support Slide

Qty:2
CTN:2




PLEASE NOTE: There are bolts which have been pre-fitted to the head and foot boards (A&B) which are not included below - please study Step 1 carefully.

**Hardware needed for fitting to the upper hole, in the side rail bracket, to the upper hole marked 'Sleepmotion Only', in the headboard & footboard - see Step (1).
Packed in Siderail Pack 3L - hardware Pack (A)**



Code	Item	Quantity
1	Bolt (M8x30mm)	4
2	Spring Washer (For M8 bolt)	4
3	Flat Washer (For M8 bolt)	4
4	Allen key (For M8 bolt)	1



Important:




Before starting assembly please refer to the owners manual supplied with your Sleepmotion electric bed base and follow the instructions taking note of any safety precautions or operational safety requirements of the installation.

In the room where bed will be used, first prepare the bed base by fitting the eight long legs - 6" (15cm).

Connect the power and check the operation then step by step follow the bed assembly instructions below, to build the bedstead around the sleepmotion bed base.

1


x8



Bolts Pre Fitted (M8x30mm)




Eight bolt sets are pre-fitted to the head & foot boards (A&B). There is no need to remove these bolts - just unscrew them by 10mm using Allen key (4).

For this Sleepmotion bed version, four extra bolt sets (1, 2 & 3) are added to the holes marked. These bolt sets can be found in hardware Pack (A).



B

A




1 x4



2 x4





3 x4



4 x1

2






Screw in the eight 6" (15cm) legs as shown.



3

Place the headboard in the final position in which the bed shall be used.


Attach the right hand side rail making sure the bed base is the correct way round with the mattress stopper at the foot end. Carefully lift and place the electric bed base into the corner between headboard and side rail as shown - it is heavy so please get help. Leave gaps as shown in the sketch at the bottom of the page.



4


Connect the power cable from the bed base to the wall socket & raise the bed as shown.

Connect the electric bed power lead to a wall socket - for safety, this must be an earthed power supply.




5

Raise the motion bed at head & foot ends & connect the footboard to the RH side rail.






6a

The long connection cable (S) and the mains power cable (M) should be laid flat between foot & head boards under the electric bed base - make sure the cables are not trapped under the legs.


**6b**

Connect the mains power lead (M)

- i) Connect the power lead (M) to your wall socket - for safety, this must be an earthed power supply.



- ii) Turn on the power to the system - please refer to the Operation Guide on Page 14.
Press the UP button to raise the TV Lift





7

Notes: For illustration purposes only, TV connections may vary.

Tip:


Before fitting the TV, push any leads through each duct from the top choosing the best side to use depending on where the connection ports are on back of your TV.
Never cross leads from one side to the other unless as shown in the instruction below.



8


Set the ruler to the height of the TV - max TV size is 98 x 57.5 x 8.5 (WHD)

Unlock




9



Lock




ii)





iii)




10




11





12



13






Keep wires tight so they can't get snagged. Peel off the cover from the rear of the cable clip and adhere to the back of the TV.




PLUG IN - KEEP ALL LEADS TIGHT - USE CLIPS & TIES PROVIDED

Optical connection detail..
REMOVE DUST-CAP




If a standard HDMI socket is situated on the rear of the TV, please use the HDMI 90° adapter (P)

14




Plug in the TV power lead




On the RC, press the DOWN button to lower the TV lift.

15




16



AUDIO OPERATION GUIDE

2.1 AUDIO SYSTEM



TURN AMPLIFIER ON or OFF.



- 1) Turn on the mains power to the TV Bed.
- 2) Press the Remote Control (RC) ON button for 2 seconds to synchronise and prepare the system, system voice shall say 'Power On'.
- 3) When finished press the OFF button for 2 seconds.

LIFT or LOWER THE TV.



Press once and TV will rise to it's upper working position. Power to the TV will be connected automatically - operate the TV using it's Operation Guide.

Press once and TV Lift will stop.

Press once and TV will go down - as soon as the lower resting position is reached, power to the TV is switched off to prevent it overheating.

NOTE: BLUETOOTH WILL WORK NORMALLY WHEN TV IS UP OR DOWN.

SELECT OPTICAL or BLUETOOTH MODE.



Select the required mode by pressing OPT (Optical) to watch TV or

Select BT (Bluetooth) to connect to your smart device to play music.

Pair your device in the normal way searching for -- 'MY BT' --.

Two devices can pair with the system but each will need to disconnect to allow the other to connect.

If a device was previously connected, system will immediately say PAIRED.

If not previously connected, system shall say PAIRING.

Note you cannot play films through the system from any BT device.



The same blue LED light bar is used to show steps for all the following controls: VOLUME, BASS & TREBLE.

VOLUME CONTROL



Use --- **+** or **-** --- button to increase or decrease the volume.

Note that this control operates step by step and as it is adjusted, the blue LED light bar follows each step until full volume is reached, then the blue lights are all on.

BASS CONTROL



Adjust the Bass attenuation - these buttons increase or decrease the lower frequencies of the sound.

TREBLE CONTROL



Adjust the Treble attenuation - these buttons increase or decrease the higher frequencies of the sound until the preferred sound level is achieved.

Note: if higher frequency sound is reduced, the volume of the sound appears to be reduced too - this is normal.

LED Lights



Switch on or off the LED light array on the rear of the headboard



Switch on or off the main LEDs on the front of the head & foot boards




This button operates the torch.



MUTE BUTTON

This button turns the sound off and back on again.

Occasionally the pairing between Remote Control & the TV bed control system is lost, usually due to atmospheric conditions. To Re-pair, please follow these instructions;



- ① Disconnect all mains electrical power to the bed for at least 60 seconds.
- ② Press either the UP or DOWN button on TV Lift Remote Control and keep holding the button down, simultaneously re-connect mains electric power to bed keeping button down for at least a further 5 seconds. The TV Lift unit receives the signal from the RC and the TV lift will begin to move UP or DOWN whichever button was pressed.
- ③ Re-pairing is now complete.

Control Panel Operating Instructions

1. Light forward button: Press button to select the next colour/light in sequence.
2. Power Button:
 - Long press- turn light on/off
 - Short press - change modes between:
 - Single Colour modes
 - Dynamic RGB modes
 - Sound Reactive control modes
3. Light return button: Press button to select the previous colour/light in sequence.

For further instructions and use of the lights, please download the Neo Motion™ Sync App



Neo Motion™ SYNC Control

Get access to over 200 patterns and unlimited customisability by downloading the Neo Motion™ App.

Compatible with Android 7 and above / IOS 12.0 and above



Technical Specifications

Max TV Size: 975 x 575 x 85 (WHDmm)

Overall Dimensions (LWH mm)

Small Double: 2240 x 1340 x 1230

Double: 2240 x 1490 x 1230


King: 2340 x 1640 x 1230

Internal Dimensions (LWH mm)

Small Double: 1930 x 1230

Double: 1930 x 1380

King: 2030 x 1530



LED Lifespan

15,000 Hours, equal to 10 years of usability (based on 4 hours usage per day)

Care & Maintenance



Cleaning

To clean your new bed, we'd advise using a warm damp cloth or if fabric, remove dust using a low suction vacuum cleaner. Please do not use abrasive chemicals or bleach as this may damage the product.



Checking and moving

Periodically we recommend you check that the screws or fixtures haven't become loose over time. To move your newbed, we recommend lifting it where possible, as dragging or pushing it could cause damage to the legs or flooring.



Wood

Please note each of our wooden pieces are unique, meaning that markings and shade can vary slightly between beds. Over a period of time, the wood might lighten or fade slightly due to light exposure.



Fabric

Please note depending on the lighting, positioning and surroundings of your room, the shade of the colour can sometimes appear slightly different. Over a period of time, the colour might lighten or fade slightly due to light exposure.



Metal

Metal tends to be more resilient to everyday wear and tear. We recommend to gently dust your metal furniture and keep it dry to maintain its look.


Thank you for shopping with us - we hope you have a great night's sleep.

Sleep well



Little dreamers

Keep the little ones entertained while you assemble your new purchase.





Dreams

Love your bed