



Hards Lane, Frognall, Deeping St James, Lincs, PE6 8RP


IMPORTANT INFORMATION!

**PLEASE READ THIS LEAFLET PRIOR TO USING
YOUR SOFA BED**

**THERE MAY BE A CABLE TIE ATTACHED TO THE
UNDERNEATH OF YOUR SOFA BED TO ASSIST WITH
TRANSPORTATION; PLEASE REMOVE THIS BEFORE
ATTEMPTING TO OPEN THE SOFA BED**

SAFETY INFORMATION

The following instructions for the opening and closing of your sofa bed should be followed to avoid the risk of possible finger entrapment.

For your safety the  symbols on Image 1 identify areas to avoid placing your hands when opening and closing your sofa bed.

NEVER allow children to play with or operate the fold-out bed actions.

CARE OF YOUR SOFA BED

- The Fabric on this product is Flame Retardant treated and therefore should be specialist upholstery cleaned only.
- Do not discard any of the packaging until you have checked the product.

Customer Care/Service for advice:

Telephone: 01778 380555; Fax: 01778 380444;

E-mail: sales@kyoto.co.uk

OPENING & CLOSING OF YOUR SOFA BED

Your sofa bed may differ in look from the images shown but the mechanism will be the same.

1. From Sofa to Bed



PLACING YOUR HAND IN THE CENTRE OF THE FRONT PLINTH, GENTLY LIFT UP AND OVER THE BOTTOM LEDGE TOWARDS YOU



PULL OUT INTO BED POSITION



2. From Bed to Sofa



LIFT FRONT OF SOFA BED UP
UNTIL IT LOCKS INTO PLACE

(AS SHOWN IN IMAGE)

NOW, PRESS DOWN TO THE
FLOOR AND PUSH.
BED WILL START TO RETURN TO
SOFA POSITION



ONCE BACK IN SOFA POSITION
GENTLY LIFT AND PUSH FRONT
OF PLINTH OVER BOTTOM
LEDGE TO LOCK INTO PLACE



KYOTO FUTONS LTD, HARDS LANE, FROGNALL,
DEEPING ST JAMES, LINCS, PE6 8RP

TEL No. 01778 380555 *** FAX No. 01778 380444

E-MAIL: sales@kyoto.co.uk

COMPANY REG No. 3007974

VAT REG No. 638 5547 06