

□ □ □ □ □ □ □ □ **d – D** □ □ □ □ □ □ □ □ **S** □ □ **r** □ □ □ □

□ □ □ □ □ □ □ **l** □ □ **r** □ □ □ □ □ □ □ □

2

**1/2**  
hours


□ □ □ □ **r** □ □ □ □


**S** □ □ □ □ **r** □ □ □ □ **r** □


□ **r** □ □ □ □ □


□ □ □ □ □ □ □ □


□ □ **d** □ □ □ □ □ □ □ □


1 















Keep glue and fittings out of children's reach.

# PARTS



## NO PART LIST

- |                 |    |
|-----------------|----|
| (1) Headboard   | 01 |
| (2) Footboard   | 01 |
| (3) Side Rails  | 02 |
| (4) Support Leg | 01 |



M



M



M



D


M r



E


S r


□ □ **SSEM** □ **L** □



- Use bolt (mounted on the headboard and footboard) to fix the Side Rail (3) onto Headboard (1) and Footboard (2) by using Allen Key (C).

**STEP 1**





## SOLID SLOTS OPTION

**NOTE:** You have bought your bed, choosing one of two slat options; either solid or sprung. Although both assembly options are explained here only one will apply to you. Please follow the correct procedure for the slat system which you have chosen.

Both slats on "step 2" and "step 3" can be assembled to the bedstead. You can make a choice between the two slats.


OPTION"A": DREAMS FIXED  
WOOD SLATS

(1) Carefully locate the slats onto the unit, as step 2:

Use bolt (A), washer (D) and JCN nut (B) to fix the unit using Allen Key (C)


(2) Fit the adjustable Support Leg (4) to the center slat. Secure with Screw (E) using Screwdriver (not provided).

## STEP 2



□ □ □ **SSEM** □ **L** □

## SPRUNG SLATS OPTION



OPTION "B": DREAMS

### SPRUNG SLATS


(1) Use the bolt to fix support leg onto the slat frame.

Please note that these bolts are to be found inside the slat frame box.



(2) Carefully locate the slats onto the unit.

(3) Use bolt (A) and JCN nut (B) to fix the unit using Allen Key (C).

### STEP 3



# SLEEPMOTION OPTION



BEFORE STARTING ASSEMBLY PLEASE REFER TO THE OWNERS MANUAL SUPPLIED WITH YOUR SLEEPMOTION 200i BED BASE AND FOLLOW THE INSTRUCTIONS TAKING NOTE OF ANY SAFETY PRECAUTIONS OR OPERATIONAL SAFETY REQUIREMENTS OF THE INSTALLATION. BUILD THE BED BASE FIRST USING ONLY THE EIGHT LONGER LEGS 6"(15cm), SEE STAGE 1. IMPORTANT: PLACE THE BASE IN FINAL POSITION IN THE ROOM OF USE, CONNECT THE POWER AND CHECK THE OPERATION THEN STEP BY STEP FOLLOW THE BED ASSEMBLY INSTRUCTIONS BELOW, TO BUILD THE BED AROUND THE SLEEPMOTION 200i BED BASE




## OPTION "C": DREAMS

### SLEEPMOTION 200i

-Place the Headboard (1) on the top edge to Sleepmotion-200i, attach the Side Rail (3) using bolt mounted on the headboard with Allen Key (C)


- place the assembled parts 10mm from the corner of Sleepmotion-200i as illustrated.

#### STEP 1






□ □ □ **SSEM** □ **L** □

## SLEEPMOTION OPTION




-Raise the Head end and foot end of the Sleepmotion-200i using the supplied remote control

STEP 2




□ □ **SSEM** □ **L** □

## SLEEPMOTION OPTION




Position the Footboard (2) to assemble with the Side Rail (3) using the bolt mounted in the Footboard with Allen Key(C)

### STEP 3





□ □ □ **SSEM** □ **L** □




## SLEEPMOTION OPTION

Make sure everything is working properly then fit second side rail


Attach the other side rail (3) to Headboard (1) and Footboard (2) using Allen Key (C).

### STEP 4



□ □ □ **SSEM** □ **L** □




## SLEEPMOTION OPTION



MAKE SURE THAT THE  
BED IS SQUARE UP AS  
SHOWN ON THE RIGHT.


FULLY TIGHTEN ALL  
BOLTS using Allen Key  
(C).

STEP 5



# ASSEMBLY

## SLEEPMOTION OPTION



Make Certain Gaps  
around the Bed Base are  
correct.

### STEP 6

