


Murphy Ottoman Bed



1.5 hour approx
assembly time



Two person
assembly

Dreams

Thank you

Hello, thanks for choosing to purchase your bed from Dreams - you're now on your way to your best ever night's sleep. Before you begin building your bed, please take a moment to read through the instructions and make sure that you've got all the relevant parts listed on the following pages.



Assembly tips

Before you begin, it's best to identify all parts and fittings to build your bed. We advise laying these out on the floor to check you have everything, and familiarising yourself before building.



Top tip

We recommend that you build your new bed in the room you'd like it to be located - this will help prevent any risk of damage to your newly built bed whilst moving it.



Safety and care

It's really important to ensure children and animals are kept away from the assembly area, as there are small components used in this bed which could present a choking hazard. All plastic and wrapping materials should also be kept away from children and animals to prevent any risk of suffocation. To keep your little ones busy, there is a colouring page inside the back cover.



Help and support

At Dreams, it's our mission to give the whole nation a great night's sleep - this means that the quality of our products is of utmost importance to us. If there are any issues with your product or any missing parts, please contact our Help Centre on 0800 652 6750, where a member of our team will be happy to help. (For customers based in Northern Ireland, please call 028 9050 8300)



Recycling

Please ensure that packaging is disposed of in a safe and environmentally friendly way, and recycle where possible. Our assembly instructions are printed on recycled paper. Please keep your assembly instructions safe to refer back to in the future.


Parts

Important information

The bed you have purchased comes with two different base options, Ottoman lift up base or Sleepmotion base. Identify which base you have purchased as the assembly method may change.

If you have purchased the Ottoman base please follow the instructions below in the current order.

If you have purchased a Sleepmotion base, please follow the assembly instructions provided in the Sleepmotion side rail pack 3L. Once the base is built please follow the AI provided in pack 3L to build your frame around the Sleepmotion Base.



Parts list

A.	Headboard	1	H.	Metal Lift up Slat Frame	1
B.	Footboard	1	I.	Mattress Stoppers	2
C.	Side rail - Left	1	J.	Cross Bar	1
D.	Side rail - Right	1	K.	Bedsides	2
E.	Slat Frame Support Rail	1	L.	Metal Legs for Bedsides	2
F.	Angle Brackets	2	M.	Power adapter with 90° LV plug	1
G.	Storage Base Boards	2			

Tools required



Tape measure







Cross head screwdriver








Fittings

Please check you have all the parts listed below with your product:

Hardware needed for fixing wings to headboard packed in headboard pack 1 - hardware pack (A)

b x6  Spring Washers for M8 bolts	c x6  Flat Washers for M8 bolts	m x6  Bolts (M8x40mm) for bolting wings to main headboard	d x1  Allen Key for M8 bolts
---	---	---	--









Hardware needed for fixing bed sides to headboard packed in headboard pack 1 - hardware pack (B)

b x4  Spring Washers for M8 bolts	c x4  Flat Washers for M8 bolts	e x4  Nuts for M8 bolts	f x4  Threaded studs (M8x60mm) for fitting bed sides (K) to headboard (A)	g x16  Screws (4x20mm) for fitting metal legs (L) to bed sides (K) (N.B. may include x4 spare screws)
h x1  Spanner for M8 nuts	Power Plug - connects the LV socket on rear of headboard to wall socket - hardware pack (C)			 Power Plug

Hardware needed for fixing side rails to headboard & footboard packed in side rail pack 3 - hardware pack (D)

a x14  Bolts (M8x30mm) for fitting side rails (C&D) to headboard & footboard (A&B)	b x14  Spring Washers for M8 bolts	c x14  Flat Washers for M8 bolts
--	--	--

Hardware needed for fitting metal slat frame, packed in side rail pack 3 - hardware pack (E)

a x8  Bolts (M8x30mm) for fitting angle brackets (F) to side rails (C&D) & footboard (B)	b x20  Spring Washers for M8 bolts	c x28  Flat Washers for M8 bolts	e x6  Nuts for M8 bolt	i x6  Bolts (M8x20mm) for fitting metal connection plates (j) and cross bar (J) to metal slat frame (H)
j x2  Metal Connection Plates	k x2  Flange lock-nuts (M8) for gas-lift pistons	l x8  Bolts (M8x45mm) for fitting metal slat frame (H) to gas-lift mechanisms & fitting slat frame support rail (E) to footboard (B)		




0 cm 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18

Folding Headboard - use pack 'A'




1




- i) Unfold wings, unzip compartments and retrieve hardware packs (A) & (B) & (C) from compartment in left hand wing.






- ii) Bolt each wing to main headboard - screw three bolt sets (m), (b) & (c) into the pre-tapped holes on each side - tighten with allen key (d).



- iii) Unclip both cables and pass through access hole into main headboard compartment.



- iv) a) Connect USB terminals together (x).
b) Connect lighting cables together (y) making certain both red cables are on same side of both the plug & the socket as shown below.
c) Re-zip compartments and headboard assembly is now complete.





Bedside assembly - use pack 'B'

2




For safety, remove glass during this step and place well away from the workplace.




Screw the threaded bolts (f) into the tapped holes in rear of the bedside chests until they stop, do not over-tighten..

3



Bed assembly – use pack 'D'





4








Bed assembly - use pack 'D'

5

Lift the Headboard into final position. Please do not drag it across the floor or the legs on the bed sides may be damaged. Also make certain the power cable is not trapped.








6



Metal slat frame assembly


use pack 'E'

7




Make certain the bed is squared up as shown in the diagram then tighten all bed assembly bolts 100%.

8




- i)** Fitting position for cross bar (J) is clearly labeled at the end of the slat frame (H). Pass the bar through the gap between first & second slat. Carefully open the frame.




- ii)** To top of slat frame, fit two connection plates (j). Using four sets of bolts (i), spring washers (b) & flat washers (c), screw into the threaded inserts on top of the frame.

Please do not tighten 100% yet.





- iii)** The cross bar fixing plates sit on top of each side of the slat frame (H), sit the plates on the round labels. Align with the threaded holes and loosely fix through the plates using bolts (i), spring washers (b) & flat washers (c).


Using Allen key (d), now tighten all six bolts 100%.





9



i) Un-tie the hinge mechanism, and take out the transit block.




ii) Hold bars forward



iii) With help from an assistant, lift slat frame (H) onto slat frame support bars aligning first set of holes on slat frame with first set of holes in support bars (nearest to headboard).



iv) Using three bolt sets on each side (b), (c), (e) & (i), fix slat frame to the support bars but do not tighten fully yet.




10



Carefully lay frame down making sure there is an even gap all round as in the sketch.




8 mm






Hold frame securely then tighten all six bolt sets 100% using spanner (h) & allen key (d).

11




During this next step, the assistant should hold up the slat frame. On side rails (C&D) slide gas-lift piston stems (X) onto the axles (Y) then fit the flange lock-nuts (k).

Tighten nuts with spanner (h) - but do not over-tighten. A small gap is needed so stems can move freely - this is important - see sketch below.




12



Push x2 Mattress Stoppers (I) into metal frame, they should go all the way through the upper & lower metal sections.

13



Note: Be very careful what you store under the bed - the top of an item, like a suitcase or a box must not touch the slats or they may be damaged. Maximum storage height is 305mm.



Before moving the slat frame, place a mattress on top of the slats as without a mattress in place the speed of movement is quick and may cause injury so be careful. Carefully lower the frame with the hand-strap ensuring the frame sides are aligned with the side rails; there should be an even gap on each side. If not aligned, check bed is still square (see Step 7) and if it is, but gaps are still not even, re-align the slat frame.

Depending on the weight of the mattress, the rising speed will vary so be careful until you get used to the speed. Always use the strap to lift or lower the frame - keep fingers well away from the moving parts.

When fully assembled and the mattress in position, please raise & lower the ottoman 4/5 times to ensure the gas pistons are fully lubricated.

Overall Dimensions (LWH cm)

Double: 211 x 230 x 112

King: 221 x 245 x 112

Internal Dimensions (LWH cm)

Double: 195 x 138 x 30.5

King: 205 x 153 x 30.5


Bedside Dimensions, (WDH cm)

42 x 34 x 56.5

Distance between slats (cm)

Double: 9

King: 8.7



Care and maintenance

Here are some tips to keep your new bed in tip-top condition



Cleaning

To clean your new bed, we'd advise using a warm damp cloth or if fabric, remove dust using a low suction vacuum cleaner - please do not use abrasive chemicals or bleach as this may damage the product.



Checking and moving

Periodically we recommend you check that the screws or fixtures haven't become loose, over time. To move your new bed, we recommend lifting it where possible, as dragging or pushing it could cause damage to your flooring.



Wood

Please note each of our wooden pieces are unique, meaning that markings and shade can vary slightly between beds. Over a period of time, the wood might lighten or fade slightly due to light exposure.



Fabric

Please note depending on the lighting, positioning and surroundings of your room, the shade of the colour can sometimes appear slightly different. Over a period of time the colour might lighten or fade slightly due to light exposure.



Metal

Metal tends to be more resilient to everyday wear and tear. We recommend to gently dust your metal furniture and keep it dry to maintain its look.

Thank you for shopping with us - we hope you have a great night's sleep

Sleep well



Little dreamers

Keep the little ones entertained while
you assemble your new purchase.



Dreams

A pink wavy line that underlines the word "Dreams".